


THE PERFECT TREE



DIRECTIONS

1. Untie electrical cords on all sections (pre-lit version).
2. Attach stand to lower spine.
3. Tighten locking screws on the stand.
4. Insert upper spine into lower spine.
(5ft & taller models have upper & lower spines).
5. Attach arms to rod in upper spine.
6. Tighten locking screws on arms.
7. Fluff branches.
8. Hide the cords by tucking them between the branches along the back of the cross (pre-lit version).

CAUTIONS

- * Be advised that there should be no more than three plugs in tandem.
- * Be advised that there should be no more than two 3-light string chains in one outlet.